## PROGRAMMING SETTING

1. Click the programming to enter the programming interface



- 2. Select the period of time of 7-day programming, press up or down to set temperatures in the different periods of time.
- 3. Enter the programming interface and then click the 7 day key
- 4. Click the date to be edited and confirm it.





\* If you need to stay out temporarily: The temperature can remain at 16°C,the energy-saving icon turns green and is on

